

EN FOLDING STOOL

Safety instructions

Please read the instructions for use carefully before using the folding stool. Observe all safety instructions to avoid damage due to improper use!

- A damaged folding stool must no longer be used!
- The product is designed for private use.
- Check for possible damage before use.
- Ensure correct folding and unfolding, otherwise there is a crushing hazard!
- The folding stool is exclusively intended for seating; please do not use as a ladder replacement.
- The folding stool must only be placed on level, hard and non-slip floors. Do not use on surfaces that are wet or smeared with oil.
- This product is not a children's toy and must not be used as gymnastics or sports equipment.
- The maximum total load of 110 kg must not be exceeded.
- When you are not using the folding stool, fold it up and store it in a place that is not accessible for children.
- The folding stool is only suitable for indoor use.

Operation

Unfolding:

To unfold, reach into the two trapezoidal opening slots on the long side and pull the folding stool apart. Do not grip the narrower, unfolding side walls (crushing hazard)!

Folding together:

Hold the folding stool at the handle of the step with one hand and pull it up.