

EN FOLDING STEP

Safety instructions

Please read the instructions for use carefully before using the folding step. Observe all safety instructions to avoid damage due to improper use!

- A damaged folding step must no longer be used!
- The product is designed for private use.
- Check for possible damage before use.
- Ensure correct folding and unfolding, otherwise there is a crushing hazard!
- The folding step must only be placed on level, hard and non-slip floors.
- Do not use on surfaces that are wet or smeared with oil.
- This folding step is not a children's toy and must not be used as gymnastics or sports equipment.
- The folding step is not suitable for sudden or abrupt (dynamic) loading. Therefore, do not jump on to the folding step.
- Only climb in the middle with both feet on the tread. Sturdy footwear must always be worn.
- Do not use any attachments to change the height of the folding step.
- The maximum total load of 150 kg must not be exceeded.
- The folding step is only intended for one person. It must not be used by two or more persons at the same time!
- When you are not using the folding step, fold it up and store it in a place that is not accessible for children.
- The folding step is only suitable for indoor use.

Operation

Unfolding:

To unfold, reach into the two trapezoidal opening slots on the long side and pull the folding step apart. Do not grip the narrower, unfolding side walls (crushing hazard)!

Folding together:

Hold the folding step at the handle of the step with one hand and pull it up.